

Thermo Scientific Orion 1517 Low Level Chloride Monitor O-ring Kit

The 1517 O-ring kit, Cat. No. 151735, contains replacement O-rings for multiple Thermo Scientific Orion chloride monitors. Some O-rings may not be used on your monitor.

The individually-packaged, medium-sized, thick, black O-ring should be used to seal the reference electrode, Cat. No. 100031, on 1517 chloride monitors with serial numbers greater than 10,000.

Use of the large size O-ring will cause air leaks around the electrode, resulting in noisy meter readings.

If you have any question, please contact Technical Support. Within the United States call 1.800.225.1480 and outside the United States call 978.232.6000 or fax 978.232.6031. In Europe, the Middle East and Africa, contact your local authorized dealer. For the most current contact information, visit www.thermo.com/water.

©2008 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.

Environmental Instruments

Water Analysis Instruments

North America

166 Cummings Center
Beverly, MA 01915 USA
Toll Free: 1-800-225-1480
Tel: 1-978-232-6000
Dom. Fax: 1-978-232-6015
Int'l Fax: 978-232-6031

www.thermo.com/water

Europe

Denmark House, Angel Drove
Ely, Cambridgeshire
England, CB7 4ET
Tel: 44-1353-666111
Fax: 44-1353-666001

Asia Pacific

Blk 55, Ayer Rajah Crescent
#04-16/24, Singapore 139949
Tel: 65-6778-6876
Fax: 65-6773-0836



255075-001 Rev.A 03-08

Thermo
SCIENTIFIC