

ORIGINAL

Document Control Number: 10005176MSDS

Revision Number: 1

Date Effective: 1/18/07

APPROVED

DRI Cannabinoid (THC) Enzyme Immunoassay- MSDS

History of Revisions			
Date	Description of Change	PCO No.	Rev No.
19 Sep 00	Address & Phone #'s were incorrect & consistency between DRI EIA and CEDIA	416-00	--
4/18/06	Create new THC Reagent Kit specific for Quest to be used with the new THC Calibrators being created specifically for QUEST, our national account, to meet their product QC requirements. The suggestion for the newly manufactured 50 and 100 ng/mL THC calibrators was recommended by Tech Ops. In order to use the newly formulated calibrators a new THC 100 kit is required to meet the high end cut off points. Removing 10009978 PSS.	421-06	0



Material Safety Data Sheet

Product: DRI[®] Cannabinoid (THC) Enzyme Immunoassay

Catalog #: 0185, 0186, 10009976

Description:

Antibody/Substrate Reagent	Liquid
Enzyme Conjugate Reagent	Liquid

Chemical Hazard/hazardous Ingredients: N/A

Fire, Explosion and Reactivity Data:

Flashpoint - Not determined.

Extinguishing media - Use extinguishing media appropriate for surrounding fire.

Unusual fire and explosion hazard - None

Reactivity - Stable. Hazardous polymerization will not occur.

Incompatibility - Avoid copper or lead plumbing. May form potentially explosive metal azides.

Health Hazards: HARMFUL IF SWALLOWED. The toxicological properties of this product has not been determined.

First Aid:

Ingestion - wash out mouth with water, provided the person is conscious. Call physician.

Inhalation - remove to fresh air. If breathing becomes difficult, give oxygen and call physician.

Skin contact - remove contaminated clothing and flush the contacted area with water and wash thoroughly with soap and water. If irritation persists call physician.

Eye contact - flush with copious amounts of water for 15 minutes. Assure adequate flushing by separating the eyelids with fingers. Call physician.

Spill and Leak Procedure: Wear appropriate protective equipment. Sweep up or absorb material and place in a closed container. Ventilate and wash spill area. If material is disposed of using plumbing always flush with a large volume of water to prevent azide build-up. Disposal should be made in accordance with existing disposal practices employed for waste at your institution. Observe all federal, state and local laws.

Special Protection Information: Provide adequate general mechanical and local exhaust ventilation. Protect eyes and skin with safety glasses and gloves. Avoid contact with eyes and skin. Do not breathe solution vapor.

Special Storage Precautions:

Avoid high temperatures (200 °F).

Do not store with acids.

Doc: 10005176-1

Date: 1/18/2007

Microgenics Corporation

46360 Fremont Blvd., Fremont, CA 94538 USA □ Tel: (510) 979-5000 □ Fax: (510) 979-5498
Technical/Customer Service (800) 232-3342